



MONTAGE

- BOOOM 10/20/32/50 AL/BR, lighter than 2 kg -
- Metal Ceiling Plate (Optional) -

1. Attach the bracket (A) to the ceiling. (Mounting screws are not included)
- 2a. Determine the height of the lamp and, if necessary, shorten the electric cable (H). The standard supplied length is 180 cm. A longer cable length is possible upon request.
- 2b. Shorten the electric cable:
 - Loosen the screw cap (G) and strain relief (F) from the ceiling plate (E).
 - Disconnect the cord at the luster terminal (C).
 - Determine the desired length.
 - Cut the cord, strip the sheath and then strip the wires to a length of about 8 mm.
 - Re-tighten the strain relief (F).
3. Connect the electricity to the luster terminal (C). Connect each wire that comes from the lamp to the same color wire that comes from the ceiling.
4. Attach the ceiling plate to the bracket with the two screws.
5. Enjoy the light.



BOOOM!

GENERAL INFORMATION


- Fitting E27, max. 40 W
- Beware of sharp edges
- Only for indoor use
- Not suitable for wet areas
- Light bulb not included

By Marc de Groot
Joris van den Berghweg 103 - B 0.03
1067 HP Amsterdam
The Netherlands



info@bymarcdegroot.com
www.bymarcdegroot.com



COMPONENTS



- (A) Mounting bracket for ceiling (screws not included)
- (B) Two screws
- (C) Luster terminal (not included)
- (D) Nut
- (E) Ceiling plate
- (F) Strain relief
- (G) Screw cap
- (H) Electricity cable and fixture



MONTAGE